



!!!WARNING!!! 220R/R0402
 When the board is powered via PoE, don't include the USB cable for to programming it!!!!
 In case this is required, USB-ISO must be used for to guarantee galvanic isolation!
 See: <https://www.olimex.com/Products/USB-Modules/USB-ISO/>

